

EXCALIBUR
REMOTE START & SECURITY PERFECTED
AL-2075-3DB-L OPERATION GUIDE

Temporary cover. Final cover is in a separate file.

Table Of Contents

Introduction.....	3
Controller & Transmitter Overview.....	4
The 2-Way Controller	4
The Controller Status Screen.....	4
The 1-Way Transmitter.....	5
Controller & Transmitter Functions.....	5
Other Remote Start Features	10
Low Voltage & High/Low Temp Automatic Starting.....	10
Turbo Timer Feature.....	10
Pit-Stop Feature	11
Manual Transmission Starting	11
Security System Features	11
Last Door Arming.....	11
Automatic Rearming.....	11
Pre-Warn Detection	12
When The System Triggers.....	12
Using The Valet Switch.....	12
Emergency Override	12
Valet Mode.....	12
The Status Light	13
Multi-Car Operation & Vehicle Profiles	14
Multi-car Operation.....	14
Programming The Vehicle Image & Name	14
Selecting Vehicle #1 or Vehicle #2 for daily use.....	14
Programming Controller Options	15
Button Lock	15
Setting The Alarm Clock.....	15
Setting The Clock	16
Power Save Mode	16
Screen Lighting	16
Selecting Button Beep.....	17
Selecting Remote Start Melodies	17
Selecting Temperature Display Unit	17
Demo Mode.....	17
Selecting Melody & Vibrate modes.....	17
Parking Timer & Remote Start Timer.....	17
Anti-Carjacking Protection	18
Programming Controllers/Transmitters.....	19
Programming Features.....	19
User Programmable Features	20
Installer Programmable Features	23

Congratulations for choosing one of the most versatile, fully-featured vehicle security and convenience systems available today. Omega Research & Development has been a leader in vehicle security products for nearly 4 decades. Please take the time to read this manual thoroughly so you can fully enjoy the benefits and features this system offers.

In this manual, you will primarily learn about 5 user interface components and how they work together in alerting you to system changes as well as how you can control system operations. Keep in mind that the operations described in this manual are written to only reflect the default system settings. Be sure to discuss any customization with your installer so you can remember any variations from this guide.

Controllers: The system has a 2-way controller that, in addition to controlling the system, it will give you confirmations on system operations as well as violation alerts. A 1-way transmitter is also included. It is a standard remote control that still gives you control over all features but without confirmations. The next section covers the controllers' operations in detail.

The Status Lights: These lights are built into the system's window-mounted antenna. They give you a visual indication of the system's current state and provide troubleshooting indicators. The operations of the status lights are covered later in this manual.

The Valet Switch: This push button gives you access to system programming, transmitter/controller programming, and valet functions. It is also built into the system's window-mounted antenna. The valet switch's operations are also covered later in this manual.

Flashing Lights: The system is connected to your vehicle's parking lights to provide a 360 degree visual confirmation, warning, & deterrence in almost all system operations. Each operation described in this manual also includes the corresponding indicator from the flashing lights. The flashing lights primarily provide visual deterrence when the system is violated.

Siren and/or Horn Sounding: The system includes an electronic siren that offers confirmation chirps during daily operations and programming. It is also the primary means of alerting anyone near your vehicle that the system has been violated. The system is capable of sounding the vehicle's horn in addition to, or in place of, the electronic siren. Most system functions have a corresponding audible alert that is described throughout this manual. Becoming familiar with these alerts will help you to instantly understand any changes in the system's status.

Controller & Transmitter Overview


THE 2-WAY CONTROLLER

Controller part number: 1512-03

- 1) **Antenna:** Sends commands to the system and receives confirmations for 2-way functions.
- 2) **OLED Display:** Displays all controller functions as well as the status of your system.
- 3) **Backlit Buttons:** Flashes while transmitting and indicates battery charging status.
- 4) **Control Buttons:** These are the primary use buttons LOCK, UNLOCK, TRUNK, & START. They are also used to navigate the controller's options.
- 5) **Charger Port:** This is where you plug in the charger to recharge the controller's battery.
- 6) **Programming Button:** This is used for setting controller features and many other functions. See "programming controller options" on page 15.



THE CONTROLLER STATUS SCREEN



*The controller is powered by a built-in rechargeable battery. When the battery level indicator shows a low battery, plug the supplied USB cable into the controller, then connect the other end to the supplied AC adapter, car adapter, or your computer's USB port. While charging, the indicator will flash from empty to full and the backlit buttons will flash once every 5 seconds while charging. When full, the indicator will be solid green and the backlit buttons will stay illuminated.

Controller & Transmitter Overview (cont'd)

NOTE: The 2-way Controller is shipped from the factory in **POWER OFF** mode. If you connect the charger before powering it, perform **POWER OFF**, then **POWER ON** again.

POWER ON: Press and hold the "P" button for at least 1 second

POWER OFF: Press the "P" and START buttons for at least 1 second

THE 1-WAY TRANSMITTER

Part number: 1513-03 E

Call your dealer or visit www.caralarm.com to order replacement transmitters.

Transmitter battery replacement:

Remove the small screw from the lower back case, and separate the transmitter halves. Replace the battery and reassemble the transmitter case.

Battery Types:

1513-03E - CR2025 (2 required)



Controller & Transmitter Functions

LOCK / ARM: Press and release the LOCK button.



- THE SIREN WILL CHIRP & THE PARKING LIGHTS WILL FLASH ONCE.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE LOCK/ARM ANIMATION AND BEEP ONCE

NOTE: PRESSING LOCK TWICE IN 5 SECONDS STARTS THE PARKING TIMER. THE CLOCK WILL CHANGE TO 0:00 AND START COUNTING IN MINUTES & HOURS.

(1-WAY TRANSMITTER: PRESS THE LOCK BUTTON)

UNLOCK / DISARM: Press and release the UNLOCK button.



- THE SIREN WILL CHIRP TWICE & THE PARKING LIGHTS WILL FLASH TWICE THEN ILLUMINATE FOR 30 SECONDS.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE UNLOCK/DISARM ANIMATION AND BEEP TWICE.

(1-WAY TRANSMITTER: PRESS THE UNLOCK BUTTON)

Controller & Transmitter Functions (cont'd)

TRUNK RELEASE / CHANNEL 2: Press the TRUNK button for 3 seconds.



- THE SYSTEM WILL DISARM AND THE TRUNK WILL OPEN (IF EQUIPPED).
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE TRUNK RELEASE ANIMATION AND BEEP TWICE

(1-WAY TRANSMITTER: PRESS AND HOLD THE TRUNK BUTTON FOR 3 SECONDS)

REMOTE START: Press and release the START button twice within 5 seconds. (see user feature #8 for additional options)



- THE PARKING LIGHTS WILL FLASH ONCE AND THE STATUS LIGHT WILL FLASH RAPIDLY.
- THE SYSTEM WILL TURN ON THE IGNITIONS AND PROCEED TO START THE ENGINE.
- ONCE THE ENGINE IS RUNNING, THE PARKING LIGHTS WILL FLASH AND THE STATUS LIGHTS WILL FLASH SLOWLY.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE REMOTE START ANIMATION AND PLAY A MELODY.
- THE CLOCK WILL CHANGE TO 0:00 TO START THE REMOTE START TIMER. IT WILL TIME HOW LONG THE ENGINE RUNS IN MINUTES & HOURS.

(1-WAY TRANSMITTER: PRESS THE START BUTTON TWICE IN 5 SECONDS)

- If the engine stalls, the system will make up to 3 more attempts.
- Each time you park your vehicle, set the climate controls to give you the desired interior temperature when you use the remote start. The engine will run for the preset run time (see user feature #1).
- **Run Time Extender:** Press the START button one time while in remote start mode to restart the engine run timer. The timer on the controller will restart at "0:00".

NOTE: This can only be used once per remote start cycle. The controller will also give you "run time expiration" warning (2 chirps) 1 minute before the remote start cycle ends.

- If you decide not to drive your vehicle, you can turn off the remote start using the same method to turn it on (Default = press START twice in 5 seconds)

NOTE: If user feature #8 is programmed for 1 press, the 1st press = Run Time Extender so an additional press is required.

- Upon entering the vehicle during remote start mode, turn the ignition key to the "ON/RUN" position (**NOT START!!**). When you press the brake pedal, the remote start will turn off allowing the ignition key to take over.

Controller & Transmitter Functions (cont'd)

CHANNEL 3: Press P then TRUNK within 5 seconds.



- YOUR SYSTEM WILL ACTIVATE THE CHANNEL 3 OUTPUT.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE CHANNEL 3 ANIMATION.

(1-WAY TRANSMITTER: PRESS AND HOLD THE TRUNK & START BUTTONS FOR 1 SECOND)

CHANNEL 4: Press P twice then TRUNK within 5 seconds.



- YOUR SYSTEM WILL ACTIVATE THE CHANNEL 4 OUTPUT.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE CHANNEL 4 ANIMATION.

(1-WAY TRANSMITTER: PRESS THE LOCK & TRUNK BUTTONS FOR 1 SECOND)

CHANNEL 5: Press P three times then TRUNK within 5 seconds.



- YOUR SYSTEM WILL ACTIVATE THE CHANNEL 5 OUTPUT.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE CHANNEL 5 ANIMATION.

(1-WAY TRANSMITTER: PRESS THE UNLOCK & START BUTTONS FOR 1 SECOND)

REMOTE VALET: Press LOCK then UNLOCK then TRUNK + START within 5 seconds.



- THE SYSTEM WILL ENTER VALET MODE. SEE PAGE 12 FOR MORE INFO ON VALET MODE.

(1-WAY TRANSMITTER: PRESS LOCK, UNLOCK, TRUNK+START)

Controller & Transmitter Functions (cont'd)

PANIC: Press and hold the LOCK or UNLOCK button for 3 seconds.



- THE SIREN/HORN WILL SOUND, THE PARKING LIGHTS WILL FLASH, AND THE DOORS WILL LOCK OR UNLOCK DEPENDING WHICH BUTTON IS PRESSED.

(1-WAY TRANSMITTER: PRESS AND HOLD THE LOCK OR UNLOCK BUTTON FOR 3 SECONDS)

SILENT ARM / DISARM: Press and release the TRUNK button twice in 5 seconds.



- THE PARKING LIGHTS WILL FLASH, AND THE DOORS WILL LOCK/ARM OR UNLOCK/DISARM DEPENDING ON THE CURRENT SYSTEM STATUS.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE LOCK/ARM OR UNLOCK/DISARM ANIMATION.

(1-WAY TRANSMITTER: PRESS RELEASE THE TRUNK BUTTON TWICE IN 5 SECONDS)

LOCK W/O ARM: Press TRUNK then LOCK within 5 seconds.



- THE DOORS WILL LOCK WITHOUT ARMING THE ALARM. IDEAL FOR RV OCCUPANTS, PETS, ETC.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE LOCK ANIMATION.

(1-WAY TRANSMITTER: PRESS TRUNK THEN LOCK WITHIN 5 SECONDS)

SENSOR BYPASS: Press and release the TRUNK button within 5 seconds of locking/arming the alarm system.



- THE SYSTEM WILL GIVE ONE CHIRP TO INDICATE THE SENSOR IS BYPASSED.
- UPON RECEIVING CONFIRMATION FROM YOUR SYSTEM, THE CONTROLLER WILL PLAY THE SENSOR BYPASS ANIMATION AND CHIRP ONCE.

(1-WAY TRANSMITTER: PRESS AND RELEASE THE TRUNK BUTTON WITHIN 5 SECONDS OF ARMING THE SYSTEM)

LOW VOLTAGE & HIGH/LOW TEMP AUTO START: Press UNLOCK, LOCK, START within 5 seconds.



- THE SYSTEM WILL GIVE ONE CHIRP TO INDICATE THE LOW VOLT/LOW TEMP (15 DEGREE ONLY) AUTO-START IS ACTIVATED. SEE PAGE 9 FOR MORE INFO.
- UPON RECEIVING CONFIRMATION, THE CONTROLLER WILL CHIRP ONCE AND THE STATUS WILL READ "RS AUTO" EVERY 5 SECONDS.

(1-WAY TRANSMITTER: PRESS AND RELEASE THE START BUTTON WITHIN 5 SECONDS OF ARMING THE SYSTEM)

VEHICLE TEMP REQUEST: Press and release "P" then START within 5 seconds.



- UPON RECEIVING CONFIRMATION, THE CONTROLLER WILL PLAY A MELODY AND THE CLOCK WILL DISPLAY THE VEHICLE'S INTERIOR TEMPERATURE.
- IF THE TEMP IS BELOW 40°F(4°C) OR ABOVE 90°F(32°C), THE CLOCK WILL ALSO READ "RS RCMD" (REMOTE START RECOMMENDED)

LOCK/UNLOCK STATUS UPDATE REQUEST: Press and release "P" then LOCK within 5 seconds.



- THE SYSTEM WILL SEND A FULL STATUS UPDATE TO THE CONTROLLER IN CASE THE STATUS CHANGED WHILE THE CONTROLLER WAS OUT OF RANGE.
- THERE IS NO AUDIBLE INDICATION FOR THIS FUNCTION.

AUXILIARY FUNCTIONS 1-4:

The actual operation of these functions will vary from car to car. They are designed to operate extra vehicle functions like automatic sliding doors or motorized hatches. Aux 1-4 are virtual outputs only available on certain vehicles when this system is integrated with the vehicle's data network. Consult your installer to find out if any of these functions are available for your vehicle. If so, confirm each operation with the controller and write each function in the blank spaces provided below.

- **Auxiliary 1 Function** (): To activate this function, press and release the TRUNK and START buttons simultaneously (or P then TRUNK).
- **Auxiliary 2 Function** (): To activate this function, press and release the LOCK and TRUNK buttons simultaneously (or P x2 then TRUNK).
- **Auxiliary 3 Function** (): To activate this function, press and release the UNLOCK and START buttons simultaneously (or P x3 then TRUNK).
- **Auxiliary 4 Function** (): To activate this function, press and release the UNLOCK and TRUNK buttons simultaneously.

Other Remote Start Features

LOW VOLTAGE & HIGH/LOW TEMP AUTOMATIC STARTING

This feature will automatically start the engine if the vehicle battery drops below 11.5 volts or the interior temperature goes above or below the pre-programmed threshold.

Programming The Low Temperature Auto Start Threshold:

- Turn the ignition switch "on", then "off" (engine not running), and within 5 seconds press the valet switch twice. The siren will chirp 3 times, within 5 seconds press the valet switch equal to the desired low temperature remote start threshold.
1 press = 0 degrees F - 1 chirp confirmation
2 presses = 15 degrees F - 2 chirps confirmation
3 presses = 32 degrees F - 3 chirps confirmation

Programming The High Temperature Auto Start Threshold:

- Turn the ignition switch "on", then "off" (engine not running), and within 5 seconds press the valet switch three times. The siren will chirp 4 times, within 5 seconds press the valet switch equal to the desired high temperature remote start threshold.
1 press = 75 degrees F - 1 chirp confirmation
2 presses = 90 degrees F - 2 chirps confirmation
3 presses = 105 degrees F - 3 chirps confirmation
4 presses = 120 degrees F - 4 chirps confirmation

Activation Using The Valet Switch

- Turn the ignition switch "on", then "off" (engine not running), and within 5 seconds press the valet switch twice. After a 2 second delay without additional valet button presses, the siren will chirp 3 times activating low battery & low/high temp auto start.

Activation Using The Controller

- Within 5 seconds, press UNLOCK, LOCK, START. The siren/horn will chirp to confirm.
- These features will operate once every two hours until the ignition key is turned "ON".
- You must activate this features each time you park your car to use them.

TURBO TIMER FEATURE

It is typically recommended that vehicles equipped with turbocharged engines allow the engine to idle for after driving to cool the turbocharger. When this Installer Programmable Feature (#10) is enabled, the system will automatically keep the engine running as follows:

- With the engine running, hold the brake pedal and engage the parking brake. When the brake pedal is released, the system will keep the engine running for the programmed time (1, 2, or 3 minutes), and then automatically turn it off.
- The system may be locked while the engine is running. Turbo Timer can be prevented from engaging, or "bypassed" if desired, by turning the engine off before engaging the parking brake, or if it's already engaged, step on the brake pedal to turn the engine off.

PIT-STOP FEATURE

This feature allows you to leave your engine running for quick errands. To use this feature, have the engine running normally from the ignition switch and your foot off the brake pedal. Press the Valet Switch twice; the parking lights will flash to confirm. Turn the key off and the engine will remain running for the programmed run time.

XL PIT STOP: Press the Valet Switch 6 times instead of 2 & the engine will run for 12 hours. Ideal for commercial applications such as refrigeration & cleaning vehicles.

MANUAL TRANSMISSION STARTING

Remote starting with a manual transmission requires that you ensure the gear selector is in NEUTRAL. There are 2 available methods.

METHOD #1 - 3D MOTION SENSOR:

This system is equipped with a 3D motion sensor built into the antenna. Whenever remote start is activated, the sensor is monitored for vehicle movement. If the vehicle moves just a few inches when the engine is cranking, it will instantly turn the engine off. This safety feature allows you to enjoy remote start without performing reservation mode as described below.

METHOD #2 - RESERVATION MODE:

For extra safety, installer feature #11 can be turned on which requires you to perform a setup procedure that ensures the transmission was left in neutral when you park your vehicle. This must be performed each time you leave your vehicle to use remote start later. To do so, follow these steps:

- 1) With the engine running via the ignition switch, hold the brake pedal, apply the parking brake, then release the brake pedal.
- 2) Use the transmitter as if you were activating remote start (default: press START twice). The status light will start to flash slow.
- 3) Turn off the ignition key and exit the vehicle, the engine will continue running.
- 4) Press LOCK on the transmitter. The engine will shut down (unless turbo timer is on) and the status light will flash every 2 seconds (ready to be remote started).

NOTE: Manual transmission starting is canceled if you enter the vehicle after performing the setup procedure.

Security System Features

LAST DOOR ARMING

See user feature #9. When this feature is enabled, the siren/horn will chirp once when all of the doors are closed. It will then start a 30 second countdown (fast flashing status light). After 30 seconds, the system will arm. During the 30 second arming delay, if a point of entry is opened, the countdown will pause until all entry points are closed again. Turning ON the ignition key will cancel the last door arming sequence until the key is turned off and the doors are all closed once again.

AUTOMATIC REARMING

This automatically rearms the alarm if the system is disarmed from the remote. (see user feature #10 to enable). When disarmed by remote, the system will start a 90 second countdown (fast flashing status light) to arm the system. This is useful if the controller may accidentally disarms the system when it's kept in a purse or pocket where other items could potentially press the buttons. ENHANCED AUTO REARM allows you to cancel the countdown by pressing UNLOCK a second time within 5 seconds of the first press to disarm the alarm.

Security System Features (cont'd)

PRE-WARN DETECTION

This system's impact sensor is designed, in addition to detecting a full impact, to warn away potential violators when it detects a light impact to the vehicle. The system will respond by chirping the siren/horn 3 times and locking the doors. This is very useful when an intruder attempts to unlock the door with "slim jim" types of devices.

WHEN THE SYSTEM TRIGGERS

It will sound the siren/horn and flash the parking lights for 30 seconds (selectable). The controller will also alert you indicating which zone is violated (if in range of the system). When disarming the system after a trigger event, the siren/horn will chirp and the lights will flash 4 times instead of the standard 2 times.

LOCK ON TRIGGER: If a door is opened when the system is triggered, it will wait until the door is closed again, then lock the doors.

STORM SAFE MODE: When the system is triggered, pressing the UNLOCK button will stop the alarm from sounding but will leave the doors locked. This function is useful if you have a false triggering situation due to violent weather.

ZONE VIOLATION RECALL: The system is capable of telling you which zones were triggered last. The system's status light will flash to indicate which zone was triggered (see the next page). This occurs during the alarm cycle AND after disarming. The system will store the last triggered zone until the vehicle's ignition key is turned on.

NUISANCE PREVENTION: If the sensor prewarns 5 times within 15 minutes, it will bypass the zone for the remainder of the 15 minutes before rearming the pre-warn zone. If a full trigger zone is left open, the system will trigger a total of 3 times before bypassing the zone. Once the zone is closed again, it will re-arm that zone.

Using The Valet Switch

EMERGENCY OVERRIDE

If you were to lose or break your controller, you'd need to perform an emergency override to disarm the system and use your vehicle. To do so, use the following steps:

STEP 1 - Enter the vehicle (the alarm should sound).

STEP 2 - Turn the ignition key to the "ON" position.

STEP 3 - Press the valet switch (located in the window-mount antenna) once.

NOTE: Enter your SecureCode at this time if programmed via user feature #13

STEP 4 - Turn the ignition key "OFF".

VALET MODE

Valet mode completely disables all security & remote start functions. Keyless entry is still operable. To enter valet mode, perform the following steps:

STEP 1 - Disarm the system by remote or by performing an emergency override.

STEP 2 - Press and hold the valet switch for 2 seconds. The system will chirp once and the status light will turn on.

EXITING VALET MODE - Press and release the valet switch once. The status light will turn off.

The status light, located in the antenna, indicates the system's current status.

SECURITY SYSTEM STATUS

OFF: The alarm is disarmed and not performing any automatic functions.

ON: The alarm is in valet mode.

FLASHING SLOW: The alarm is armed and monitoring all entry points.

FLASHING FAST: One of the automatic arming features is in progress.

AUTOMATIC TRANSMITTER VERIFICATION

Every time you turn on the ignition key, the status light will flash a number of times equal to the number of transmitters programmed to the system. This unique security feature combats potential thieves (valet attendant, mechanic, etc.) from adding their own transmitter without your knowledge and accessing your vehicle at a later time.

ALARM ZONE VIOLATION RECALL

If the security system is triggered, upon disarming, the status light will flash a number of times to indicate exactly which zone(s), has been violated. It will store the last 2 violated circuits and continually repeat the flash pattern until the vehicle's ignition key is turned ON.

2 FLASHES: Hood trigger

3 FLASHES: Door trigger

4 FLASHES: Sensor port trigger

REMOTE START STATUS

FLASHING SLOW: The engine was remote started successfully and is running.

FLASHING FAST: The remote start sequence has begun and is in process of starting.

2 FLASHES, PAUSE: The engine is running while the alarm is armed.

REMOTE START DIAGNOSTICS

The remote start system can also indicate which zone caused the last remote start cycle to end. To see this indicator, place the system into alarm valet mode. Immediately after the chirp, the status light will flash to indicate which zone violation occurred.

1 FLASH: The hood was opened.

2 FLASHES: Brake pedal was pressed

3 FLASHES: Bad tach signal or engine overrev.

4 FLASHES: The neutral safety circuit was triggered.

5 FLASHES: The 3D sensor detected vehicle motion.

6 FLASHES: Received command to stop.

7 FLASHES: The alarm was triggered.

8 FLASHES: Run time expired.

9 FLASHES: Low battery voltage was detected.



Multi-Car Operation & Vehicle Profiles

MULTI-CAR OPERATION

The controller can operate up to 2 different systems. When controlling 2 systems, it will receive all status updates on the currently selected vehicle profile and will receive only trigger alerts for the 2nd vehicle. You can switch from one car to the other at any time as well as choose a unique image and name for each vehicle. Use the following steps to change vehicle profiles as well as select the vehicle image and name.

PROGRAMMING THE VEHICLE IMAGE & NAME

Programming Controls



- Press for 3 seconds to access the options menu.
- Press and release to return to the status screen.

- 1) Press the “P” button for 3 seconds to access options.
- 2) Scroll down until “Vehicle Info” is highlighted (pictured to the left above).
- 3) Press the ✓ button to select.
- 4) Scroll to highlight Vehicle #1 or Vehicle #2
- 5) Press the ✓ button to select.
- 6) The image option will be highlighted. Scroll up or down to change the image. (pictured to the left)
- 7) Press the ✓ button to select.
- 8) The first letter of the name is highlighted. Use the up and down arrows to scroll through the alphabet/numbers. Press the ✓ button to move to the next space. Press ← to move back a space. The name can be up to 8 characters.

After selecting the 8th character, you will return to the Vehicle #1/#2 selection screen. Press the “P” button to return to status screen or press the ← button to return to the main menu.

SELECTING VEHICLE #1 OR VEHICLE #2 FOR DAILY USE

Press the “P” then UNLOCK select Vehicle #1. The controller will beep/vibrate once. Repeat to select Vehicle #2. The controller will beep/vibrate twice.

Programming Controller Options


Each function button on the controller also serves for navigating through the option menus and making changes to the controller options. These secondary functions are indicated by small icons in the upper corners of each button. See below for an explanation of each button's function.

Programming Controls



- Press for 3 seconds to access the options menu.
- Press and release to return to the status screen.


BUTTON LOCK



This feature disables the function buttons from operating when pressed. This prevents accidental system activation. To activate:

- 1) Press the "P" button to access the options menu.
- 2) "Button Lock" will be highlighted by default.
- 3) Press the ✓ button to select. All function buttons are now locked.
- 3) To unlock the buttons, press **START** then **UNLOCK**.

SETTING THE ALARM CLOCK




*To disable, perform steps 1-5 but select OFF on step 4

**The alarm clock has an optional 24 hour format (see "setting the clock")

- 1) Press the "P" button to access the options menu.
- 2) Scroll down until "Alarm Clock" is highlighted
- 3) Press the ✓ button to select.
- 4) Scroll down to highlight ON.*
- 5) Press the ✓ button to select.
- 6) The hour will now be highlighted. Scroll to select the desired hour.
- 7) Press the ✓ button to select.
- 6) The hour digits will now be highlighted. Scroll to select the desired hour.
- 8) Press the ✓ button to select.
- 9) The minute digits will now be highlighted. Scroll to select the desired minute setting.
- 10) Press the ✓ button to select.
- END HERE IF CLOCK IS IN 24 HOUR FORMAT
- 11) AM/PM will now be highlighted.** Scroll to select the desired setting.
- 12) Press the ✓ button to select.


Programming Controller Options (cont'd)

SETTING THE CLOCK



- 1) Press the "P" button to access the options menu.
- 2) Scroll down until "Set Clock" is highlighted
- 3) Press the ✓ button to select.
- 4) Scroll to highlight either 12 (AM/PM) or 24 hour format.
- 5) Press the ✓ button to select. (the hour is highlighted)
- 6) Scroll to select the desired hour.
- 7) Press the ✓ button to select. (the hour is highlighted)
- 6) The hour digits will now be highlighted. Scroll to select the desired hour.
- 8) Press the ✓ button to select.
- 9) The minute digits will now be highlighted. Scroll to the desired minute setting.
- 10) Press the ✓ button to select.
- END HERE IF CLOCK IS IN 24 HOUR FORMAT
- 11) AM/PM will now be highlighted. Scroll to select the desired setting.
- 12) Press the ✓ button to select.

POWER SAVE MODE




The 2-way portion of the controller can be disabled completely to save battery life while traveling or out of range of the vehicle. To set power save:

- 1) Press the "P" button to access the options menu.
- 2) Scroll down until "Power Save" is highlighted
- 3) Press the ✓ button to select.
- 4) Scroll to select ON or OFF, whichever is desired.
- 3) Press the ✓ button to select.



When Power Save mode is ON, you will not receive any 2-way confirmations. Additionally, there will be a red X over the "in range" indicator in the lower left corner of the status screen (pictured to the left).


SCREEN LIGHTING



This option selects how long the screen will stay lit before turning back off. Keep in mind that longer settings sacrifice some battery life. To program:

- 1) Press the "P" button to access the options menu.
- 2) Scroll down until "Screen Lighting" is highlighted
- 3) Press the ✓ button to select.
- 4) Scroll to select the desired time interval.
- 3) Press the ✓ button to select.


SELECTING BUTTON BEEP



With this option turned ON, the controller will beep to confirm each button press. The default setting is OFF. To turn ON/OFF, use the following procedure:

- 1) Press the "P" button for 3 seconds to access options.
- 2) Scroll down until "Button Beep" is highlighted
- 3) Press the ✓ button to select.
- 4) Scroll up or down to highlight the desired setting.
- 5) Press the ✓ button to select.

SELECTING REMOTE START MELODIES



This option allows you to select from 5 different melodies to indicate when remote start is turned on and off. To change the setting, use the following procedure:

- 1) Press the "P" button for 3 seconds to access options.
- 2) Scroll down until "Melodies" is highlighted
- 3) Press the ✓ button to select.
- 4) Scroll up or down to highlight the desired setting.
- 5) Press the ✓ button to select.

SELECTING TEMPERATURE DISPLAY UNIT

This option allows you to select Fahrenheit or Celsius for the temperature display:

- 1) Press the "P" button for 3 seconds to access options.
- 2) Scroll down until "Temp Display" is highlighted
- 3) Press the ✓ button to select.
- 4) Scroll up or down to highlight the desired setting.
- 5) Press the ✓ button to select.

DEMO MODE

Demo mode will show you a demonstration movie of all the controller's confirmation animations and alerts. To view demo mode, use the following steps.

- 1) Press the "P" button for 3 seconds to access options.
- 2) Scroll down until "DEMO" is highlighted
- 3) Press the ✓ button to select.

SELECTING MELODY & VIBRATE MODES

The controller can give you 2-way alerts with a melody, vibration, or both. By default, the controller is set for melody only. **Press the "P" and trunk buttons simultaneously for 2 seconds to change the setting.** The sequence is VIBRATE only, MELODY + VIBRATE, MELODY only. The melody and vibrate icons at the top of the status screen will change to indicate your selection.

PARKING TIMER & REMOTE START TIMER

PARKING TIMER: Press LOCK twice within 5 seconds to start the timer.

REMOTE START TIMER: This turns on every time you remote start.

Note: Pressing the "P" during either timer mode will switch between the timer and clock.

Anti-Carjacking Protection

The system is equipped with two separate Anti-Carjacking protection features (ignition, open door, or both). All are programmable, and must be turned on to operate. Once activated, the user has 60 seconds to cancel the Anti-Carjacking protection process (described below). If Anti-Carjacking is not cancelled, 53 seconds after being activated the siren will begin to chirp for 7 seconds to alert the user that the system is about to enter into an alarm condition. The Valet Switch may still be pressed once during this period to cancel the Anti-Carjacking process.

If the Anti-Carjacking process is not cancelled before the 60 second countdown expires, the system will enter an alarm condition, sounding the siren and flashing the parking lights. 30 seconds after this occurs, or should the ignition be turned off in the meantime, the siren interrupt will engage. Once the system enters the alarm condition, it will not respond to the transmitter, nor will the system reset automatically after 60 seconds, and it can only be disengaged by:

Step 1 Turning the vehicle's ignition off.

Step 2 Turning the ignition back on.

Step 3 Within 5 seconds, perform an Emergency Override using the Valet Switch. If the SecureCode has been customized, the correct number of Valet Switch presses must be made.

The different types of Anti-Carjacking protection are:

Ignition Activated Anti-Carjacking activates every time the vehicle's ignition is turned on. The Valet Switch must be pressed within 60 seconds of activating to cancel Anti-Carjacking. This is User Programmable Feature #12.

Door Anti-Carjacking activates when a door is opened after the vehicle is started and the engine is running. The Valet Switch must be pressed within 60 seconds after activation to cancel Anti-Carjacking. This is User Programmable Feature #12.

Programming Controllers/Transmitters

Standard Programming: Use this method to program additional or replacement transmitters. Before you begin, have all transmitters at hand and make sure the correct vehicle profile (see page 12) is selected on the controller(s).

Step 1 Then, turn the ignition “on”.

Step 2 Within 5 seconds of Step 1, press the Valet Switch 5 times. The siren/horn will briefly sound, confirming that the system is ready to learn a transmitter code.

Step 3 Press the **LOCK** button on each transmitter one at a time. The system will chirp the siren/horn once to confirm that each was learned. If a code is not received within 10 seconds of Step 2, the learning process will automatically exit.

Programming Features

Step 1 Turn the ignition key “ON”, then “OFF”.

Step 2 Within 5 seconds of step 1, press the valet switch 5 times to access user features (10 times to access installer features).

~ The siren/horn will sound and the status light will turn on.

Step 3 Within 10 seconds of step 2, press the valet switch the number of times corresponding with the desired feature's number.

~ The siren/horn will chirp, the status lights, and the parking lights will flash equal to the selected feature.

Step 4 Change the feature by pressing the transmitter button that corresponds with the desired setting. The siren/horn will chirp to correspond with the chosen setting.

User Programmable Features

Feature #1 - Remote Start Run Time

- 3 Minutes** (press LOCK to program)
- 10 Minutes** (press UNLOCK to program)
- 15 Minutes** (press TRUNK to program)
- 20 Minutes** (press START to program)
- 30 Minutes** (press LOCK & UNLOCK to program)

This sets the maximum amount of time that the remote start will keep the engine running if it is not shut down by other methods.

Feature #2 - Flashing Light Confirmations

- Unlock: ON, RS: ON** (press LOCK to program)
- Unlock: ON, RS: Flash** (press UNLOCK to program)
- Unlock: Flash, RS: ON** (press TRUNK to program)
- Unlock: Flash, RS: Flash** (press START to program)

This feature affects the parking light confirmations for system unlock & remote start functions. With the above options, you can select any combination of:

- Unlock: Flash** - Flashes twice after unlock
- Unlock: ON** - Flashes twice then stays on for 30 seconds after unlock
- RS: ON** - Stays on during remote start mode
- RS: Flash** - Flashes once every 1.5 seconds during remote start mode

Feature #3 - Confirmation Chirp Volume

- Low (softest)** (press LOCK to program)
- Medium Low** (press UNLOCK to program)
- Medium High** (press TRUNK to program)
- High (loudest)** (press START to program)

This feature allows the choice different chirp volume levels, and when programming it, each selection will be confirmed in the chosen volume making it easy to choose the most suitable setting.

Feature #4 - BROWN Wire Audible Output

- Pulsed Horn Low** (press LOCK to program)
- Pulsed Horn Medium** (press UNLOCK to program)
- Pulsed Horn High** (press TRUNK to program)
- Steady Siren** (press START to program)
- Random** (press LOCK & UNLOCK to program)

This changes the BROWN wire's audible output when the alarm is triggered. Steady siren must be selected when using a siren (other horn outputs stay at the Medium setting). The random option will pulse the horn in a distinct long and short honk routine during the alarm trigger condition. The horn honk options will affect all horn honk outputs used as well as change the BROWN wire's function. If installer feature #6 is set to "Horn" the Brown wire will function as a steady siren when "Random" is selected.

Feature #5 - Ignition Controlled Lock/Unlock

- Off** (press LOCK to program)
- Lock w/ Ignition On** (press UNLOCK to program)
- Unlock w/ Ignition Off** (press TRUNK to program)
- Lock And Unlock w/ Ignition** (press START to program)

This feature controls the lock/unlock operations when the ignition key is turned on/off.

Feature #6 - Open Door Bypass of Ignition Locking

On (press LOCK to program)

Off (press UNLOCK to program)

This feature cancels the automatic locking or unlocking of the vehicle's doors if one of the doors is open when the ignition switch is turned on or off.

Feature #7 - Unlock w/ Trunk Release

On (press LOCK to program)

Off (press UNLOCK to program)

"2nd channel" is most commonly used for trunk release, in which case the alarm should also disarm. This feature, when on, configures the system to unlock/disarm when the 2nd channel is activated.

Feature #8 - Remote Start Activation From The Remote

Press START button 1 time (press LOCK to program)

Press START button 2 times (press UNLOCK to program)

Press START button 3 times (press TRUNK to program)

Press START button 4 times (press START to program)

This feature changes how the remote start feature is activated from the remote.

Feature #9 - Last Door Arming

Off (press LOCK to program)

On w/o doors locking (press UNLOCK to program)

On w/ doors locking (press TRUNK to program)

"Last Door Arming" has the system automatically arm itself every time you exit the vehicle (the complete operation is described on page 8).

Feature #10 - Automatic Rearming

Off (press LOCK to program)

On w/o doors locking (press UNLOCK to program)

On w/ doors locking (press TRUNK to program)

Enhanced auto rearm (press START to program)

"Automatic Rearming", described on page 9, rearms the alarm if accidentally disarmed. Options are to have Automatic Rearming operate with or without also locking the doors when the system does rearm. Enhanced auto rearm allows you to cancel the rearming sequence by pressing unlock a 2nd time after disarming.

Feature #11 - Confirmation Chirps

Siren + Horn (press LOCK to program)

Siren Only (press UNLOCK to program)

Horn Only (press TRUNK to program)

On Demand (siren+horn) (press START to program)

Off (press LOCK & UNLOCK to program)

This feature selects whether the siren and/or horn give confirmation chirps. Both outputs will always sound when the alarm system is triggered or in panic mode.

Feature #12 - Anti-Carjacking

Ignition Only (press LOCK to program)

Door Only (press UNLOCK to program)

Ignition + Door (press TRUNK to program)

Off (press START to program)

This selects between the 2 forms of anti-carjacking protection. Details on using anti-carjacking protection are described on page 14.

User Programmable Features (cont'd)

Feature #13 - SecureCode

DEFAULT - 1 Press

SecureCode is a unique patented feature which allows you to select the number of Valet Switch presses in two stages, instead of "1 press", which would be required in order to perform an Emergency Override. If any of the three anti-carjacking features are utilized, a customized SecureCode would also be required to turn it off once it is fully activated. SecureCode operation is described on page 10.

To custom program a new SecureCode:

Step 1 Access user feature #13 (follow the steps on page 15).

Step 2 Within 10 seconds slowly press and release the transmitter's LOCK button the number of times equal to the desired SecureCode for stage 1, allow the system to respond to each transmitter button press with a siren chirp before pressing the button again. A few seconds after the final button press, the system will chirp confirming the total number for stage 1.

Step 3 Configure stage 2 of the SecureCode by pressing and releasing the LOCK button again equal to the number of times desired for the stage 2. The system will confirm as it did for stage 1.

NOTE: To start over, press the valet button 13 times again.

Feature #14 - Ignition Activated Override

On (press LOCK to program)

Off (press UNLOCK to program)

This feature allows an activated system to be overridden and disarmed by simply turning the ignition switch on within 10 seconds of the alarm triggering. After 10 seconds, the Emergency Override must be performed.

Feature #15 - Alarm Trigger Duration

30 Seconds (press LOCK to program)

60 Seconds (press UNLOCK to program)

90 Seconds (press TRUNK to program)

120 Seconds (press START to program)

This feature selects the period of time for which the system sounds the siren (and/or horn) and flashes the lights when triggered. **Caution: Before lengthening the Alarm Duration you should always check and determine if there are any local anti-noise or nuisance ordinances in your area.**

Feature #16 - Arming Delay

3 Seconds (press LOCK to program)

15 Seconds (press UNLOCK to program)

30 Seconds (press TRUNK to program)

45 Seconds (press START to program)

This selects how long the alarm waits to monitor trigger zones after arming.

Feature #17 - Open Door Warning Upon Arming

On (press LOCK to program)

Off (press UNLOCK to program)

When this feature is turned on, if one of the vehicle's doors is open at the time that the system is armed via the controller or transmitter, the siren will chirp 3 times and the parking lights will flash 3 times, instead of once.

Installer Programmable Features

This group of Installer Programmable Features are all accessed as a group in the second level of features' programming. These features have a direct affect upon the system's operations related to the installation and vehicle type **AND SHOULD ONLY BE CHANGED BY THE INSTALLER!!!**

Feature #1 - Remote Start Activation From The WHITE/BLUE Wire

- 1 pulse (press LOCK to program)
- 2 pulses (press UNLOCK to program)
- 3 pulses (press TRUNK to program)
- 4 pulses (press START to program)

This feature changes how remote start is activated from the (-) activation input wire.

Feature #2 - Vehicle Learn

- Enabled (press LOCK to program)
- Disabled (press UNLOCK to program)

When enabled, the system will allow the installer to perform vehicle learn (described in the installation guide). This allows quick programming of several vehicle specific settings.

WARNING: This feature should only be programmed by the installer.

Feature #3 - Engine Detection Method

- Progressive Voltage (press LOCK to program)
- Voltage (press UNLOCK to program)
- Tach Wire (press TRUNK to program)
- Data Tach (press START to program)
- Crank Only (press LOCK & UNLOCK to program)

This feature selects the method in which the remote start monitors the engine's running condition in remote start mode. The best method available is auto-detected during the VEHICLE LEARN process.

"Progressive Voltage" mode is a new version of our popular "tachless hi" method. It uses a preset crank time (see installer feature #7) and monitors the vehicle's voltage level to determine if the engine is running. This setting looks for a voltage increase of 0.3v after cranking but allows for voltage drops after the engine is running for 2 minutes accommodating new progressive style alternators. This method is the most universal for all vehicles.

"Voltage" mode looks for a voltage increase of 0.5v after cranking and constantly monitors voltage during remote start operation.

"Tach Wire" Before this setting is programmed, refer to the "Violet/White wire" section of the installation manual for proper wiring connection and the Tach Learn Procedure. It will crank the engine for up to 3 seconds or until a tach signal is detected.

"Data Tach" mode operates just like the "Tach Wire" setting except it takes its reading from the D2D data port instead of using the Violet/White wire. Before using, make sure this function is supported by the Databus Interface module.

"Crank Only" AKA "blind start" is similar to the "Tachless" settings however, it only makes one start attempt and does not monitor engine running conditions. This is useful for many "push-to-start" vehicles.

Feature #4 - Gasoline Or Diesel Engine

- Gasoline (press LOCK to program)
- Diesel 15 Sec. Delay (press UNLOCK to program)
- Diesel 20 Sec. Delay (press TRUNK to program)
- Diesel 30 Sec. Delay (press START to program)

This feature changes the system's timing of the ignition and starter output sequence for gas or diesel engines. Gasoline: the starter output will occur 3 seconds after the ignitions turn on. When in "Tachless" mode, the engine running status is determined 10 seconds after starting. Diesel: the starter output will occur 15, 20, or 30 seconds after the ignitions turn on (allows for glow plug warming). When in "Tachless" mode, the engine running status will be determined 40 seconds after cranking.

Installer Programmable Features (cont'd)

Feature #5 - Light Relay Function

Dome Light Output	(press LOCK to program)
Start	(press UNLOCK to program)
Ignition Output	(press TRUNK to program)
Accessory Output	(press START to program)
Status	(press LOCK & UNLOCK to program)
Light Flash	(press TRUNK & START to program)

The system has two built-in relays, which can be programmed to perform several different functions. The primary function of this relay, is to use for vehicle with multi-plex parking light systems. This relay can be programmed for any other functions listed above.

Feature #6 Blue Satellite Port, Blue Wire Function

Ignition	(press LOCK to program)
Status / GWR	(press UNLOCK to program)
Defrost 0.8 sec Pulse	(press TRUNK to program)
Defrost 10 min Pulse	(press START to program)
Pulse After Engine Off	(press LOCK & UNLOCK to program)
Horn	(press TRUNK & START to program)

This determines the function of the Blue wire on the Blue satellite relay port.

The Status setting turns on briefly before the Ignition output and stays on during remote start mode. The other pulse settings give a 0.8 second pulse under the selected condition. **Defrost Pulse** will send a pulse after start only when the cabin temperature is below freezing (32 degrees F / 0 degrees C).

Feature #7 - Starter Cranking Time

0.75 Second	(press LOCK to program)
1.00 Second	(press UNLOCK to program)
1.5 Seconds	(press TRUNK to program)
2.25 Seconds	(press START to program)
3 Seconds	(press LOCK & UNLOCK to program)
Average	(press TRUNK & START to program)

This feature determines the crank time of the 1st start attempt when in "Tachless" mode. If the engine doesn't start on the first attempt, it will retry up to 3 more times extending the crank time by an additional 0.2 second with each attempt. The "Average" setting will sample the last 8 cranks (by ignition key) and average the crank time automatically for increased accuracy.

Feature #8 - Door Lock/Unlock Outputs

0.8 Second Outputs	(press LOCK to program)
3 Second Outputs	(press UNLOCK to program)
Double Pulse Unlock Output	(press TRUNK to program)
Total Closure Lock Output	(press START to program)

This changes the system's door lock outputs to suite different vehicle requirements. The total closure setting provides a 28 second lock pulse (press LOCK or UNLOCK is during the pulse to stop it) and a 0.8 second unlock pulse.

Feature #9 Remote Start Lock Control

Off	(press LOCK to program)
Lock After Start	(press UNLOCK to program)
Unlock Before Start	(press TRUNK to program)
Unlock Before Start & Lock After Start	(press START to program)
Lock After Engine Off	(press LOCK & UNLOCK to program)

This feature allows for OEM alarm/lock control in relation to remote start operations thus eliminating extra wiring for OEM alarm control.

Feature #10 - Turbo Timer

- Off (press LOCK to program)
Run 1 Minute (press UNLOCK to program)
Run 2 Minutes (press TRUNK to program)
Run 3 Minutes (press START to program)

This feature, the operation of which is described on page 8, when turned on configures the system to automatically keep the engine running briefly after the key is turned off. This operation is designed specifically for vehicles with turbocharged engines.

NOTE: This feature is dependent on the proper wiring of the neutral safety circuit.

Feature #11 - Manual Transmission Reservation Mode

- On (press LOCK to program)
Off (press UNLOCK to program)

This feature changes the parameters of the system's remote start operation to be suitable for manual transmission-equipped vehicles via a "setup" procedure which must be followed upon exiting the vehicle to ensure the transmission is in neutral.

Feature #12 - Data Port Protocol

- Green: DBI, Black: DBI (press LOCK to program)
Green: iData, Black: iData (press UNLOCK to program)
Green: DBI, Black: iData (press TRUNK to program)
Green: iData, Black: DBI (press START to program)

This feature determines which data protocol is used on each data port. Choose this based on the accessory being connected to the port. **NOTE:** When a BLADE is inserted, this feature automatically switches the black port to the iDataLink protocol.

Feature #13 - Alarm Functions

- On (press LOCK to program)
Off (press UNLOCK to program)
Off- Unlock Only (press TRUNK to program)
Sensor Detect (press START to program)

This feature converts keyless entry models to full alarm systems (installation changes may be required). **Sensor Detect** automatically turns on alarm functions when a sensor is connected to the sensor port or data port.

Feature #14 - Pulse Ignition On Disarm

- On (press LOCK to program)
Off (press UNLOCK to program)

This feature will pulse the ignition and activate any attached immobilizer bypass module for vehicles that require the ignition to be turned on to disarm the OEM alarm.

Feature #15 - Lock On Prewarn

- On (press LOCK to program)
Off (press UNLOCK to program)

This feature will automatically lock the doors to combat unauthorized entry from lock picking when the prewarn zone is triggered.

Feature #16 - Starter Interrupt Functions

- Alarm Only (press LOCK to program)
Anti-Grind Only (press UNLOCK to program)
Alarm & Anti-Grind (press TRUNK to program)
Automatic (press START to program)

Alarm Only - The Starter Interrupt is operable whenever the alarm is armed.

Anti-Grind Only - The Starter Interrupt is operable whenever remote start is on.

Alarm & Anti-Grind - This setting engages starter interrupt when the alarm is armed AND when the system is in remote start mode.

Automatic - The Starter Interrupt output will automatically engage 90 seconds after the ignition switch is turned "off", and after disarming the system.

Installer Programmable Features (cont'd)

Feature #17 Low Temp Crank Extender

0ms	(press LOCK to program)
200ms	(press UNLOCK to program)
300ms	(press TRUNK to program)
400ms	(press START to program)

When the vehicle's interior temperature is below freezing, this feature adds extra crank time to the base timing (see installer feature #7). It applies to tachless modes only (installer feature #3).

Feature #18 - Arm, Disarm or Additional Channels

Arm / Disarm	(press LOCK to program)
Arm / Channel 5	(press UNLOCK to program)
Ch 4 Pulse / Disarm	(press TRUNK to program)
Ch 4 Pulse / Ch 5 Pulse	(press START to program)
Ch 4 Latch / Disarm	(press LOCK & UNLOCK to program)
Ch 4 Latch / Ch 5 Pulse	(press TRUNK & START to program)

The system has outputs designed for arming and/or disarming a factory-equipped security system. These wires may be used instead to provide further system outputs, which are remotely operated by the controller. These outputs are in addition to the 2nd channel and 3rd channel outputs. As shown in the programming assignment, the arm, disarm, channel 4 and channel 5 are programmable as various combinations. The Channel 4 Latch function will reset when the remote button(s) is pressed again, the ignition is turned "on", or the system loses main power.

Feature #19 - Horn Relay Function

Horn Output	(press LOCK to program)
Ignition	(press UNLOCK to program)
Trunk Release	(press TRUNK to program)
Pulse After Start	(press START to program)

The primary function of this second relay, is to operate the vehicle's existing horn; either in conjunction with the electronic siren, or in place of the siren. Using both a siren and the horn creates an extremely effective security system.

Feature #20 Low Current / Motorcycle Mode

On	(press LOCK to program)
Off	(press UNLOCK to program)

This feature, when on, reduces the system's current draw by as much as 40% while the alarm is armed. It causes the starter interrupt output to only operate when the ignition is turned on and reduces the frequency of the "armed" flashing status light significantly. This is ideal when the system is to be used on vehicles that have limited battery capacity and/or may sit for extended periods without charging the battery.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning! Changes or modifications made to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

User Feature Programming: Ignition on, off, press valet 5 times

	# Feature	Lock Button (Brake 1x)	Unlock button (Brake 2x)	Trunk button (Brake 3x)	Start button (Brake 4x)	Lock + Unlock (Brake 5x)	Trunk + Start (Brake 6x)
CONVENIENCE	1 Remote Start Run Time	3 min	10 min	15 min	20 min	30 min	
	2 Flashing Light Confirmations	Unlock: ON RS: ON	Unlock: ON RS: Flash	Unlock: Flash RS: Flash	Unlock: Flash RS: Flash		
	3 Confirmation Chirp Volume	Low	Med-Low	Med-High	High		
	4 BROWN Wire: Siren / Pulsed Horn	Pulse LOW	Pulse MED	Pulse HI	Steady Siren	Random	
	5 Ignition Lock / Unlock	Off	Ign On = Lock	Ign. Off = Unlock	Lock + Unlock		
	6 Door Open Bypass for Feat. #5	On	Off				
	7 Unlock w/ Trunk Release	On	Off				
	8 RS Activation (Remote)	Start x 1	Start x 2	Start x 3	Start x 4		
SECURITY	9 Last Door Arming	Off	On w/o Lock	On w/ Lock			
	10 Automatic Rearming	Off	On w/o Lock	On w/ Lock	Enhanced		
	11 Confirmation Chirps	Siren + Horn	Siren Only	Horn Only	On Demand	Off	
	12 Anti-Carjacking	Ignition	Door	Ignition + Door	Off		
	13 Override Code	See operation guide for programming instructions. DEFAULT: 1,0					
	14 Ignition Override	On	Off				
	15 Alarm Trigger Duration	30 sec	60 sec	90 sec	120 sec		
	16 Arming Delay	3 sec	15 sec	30 sec	45 sec		
	17 Open Door Warning Upon Arming	On	Off				

Installer Feature Programming: Ignition on, off, press valet 10 times

INSTALLER ONLY	1 RS Activation (WHITE/BLUE wire)	1 Pulse	2 pulses	3 pulses	4 pulses		
	2 Vehicle Learn	Enabled	Disabled				
	3 Engine Detection	Prog. Voltage	Voltage	Tach Wire	Data-tach	Crank Only	
	4 Gasoline or Diesel Engine	Gasoline	15 sec Diesel	20 sec Diesel	30 sec Diesel		
	5 Light Relay Function	Dome Light	Start	Ignition	Accessory	Status	Light Flash
	6 Blue Sat Port BLUE Wire	Ignition	Status	0.8 sec Defrost Pulse	10 min Defrost Pulse	Pulse After Engine Off	Horn
	7 Crank Time	0.75 sec	1 sec	1.5 sec	2.25 sec	3 sec	Average
	8 Door Lock/Unlock Outputs	0.8 sec	3 sec	Double Unlock	Total Closure		
	9 Remote Start Lock Control	Off	Lock After Start	Unlock before Start	Unlock Before & Lock After	Lock After Engine Off	
	10 Turbo Timer	Off	1 min	2 min	3 min		
	11 Manual Transmission Reservation	On	Off				
	12 Data Port Protocol	Green: DBI Black: DBI	Green: iData Black: iData	Green: DBI Black: iData	Green: iData Black: DBI		
	13 Alarm Functions	On	Off	Off-Unlock Only	Sensor Detect		
	14 Pulse Ign. on Disarm	On	Off				
	15 Lock On Prewarn	On	Off				
	16 Starter Interrupt	Alarm Only	Anti-grind Only	Alarm/Anti-Grind	Automatic		
	17 Low Temp Crank Extender	0 ms	200 ms	300 ms	400 ms		
	18 Arm/Disarm or CH. 4/5	Arm/Disarm	Arm/CH5 Pulse	CH4 Pulse/ Disarm	CH4 Pulse/ CH5 Pulse	CH4 Latch/ Disarm	CH4 Latch/ CH5 Pulse
	19 Horn Relay Function	Horn	Ignition	Trunk Release	Pulse After Start		
	20 Low Current Mode	On	Off				

FEATURE SETTING KEY:
Default Setting

Back Cover

**Color cover is in a
separate file.**