


HONDA 2005 ODYSSEY DOORLOCK INTERFACE



PROGRAMMING:

Once all wire connections have been properly made:

1. Plug the 10 pin connector into module. The LED should turn on to confirm correct connection
2. Insert vehicle's key into ignition cylinder. The module's LED should turn off
3. The module is now programmed

PROGRAMMABLE FEATURES:

1. With the ignition off, press and hold the programming button for 2 seconds. The LED will flash for approx. 3 seconds, pause, then flash once more to indicate that the module is in feature one.
2. Each time the program button is pressed, the module will advance to the next feature (only features 1 & 8 are used)
3. After selecting the desired feature, you can change the setting by applying a ground pulse to the Green "lock" wire or the Blue "unlock" wire. The horn will honk once for the lock wire and twice for the unlock wire.
4. To exit programming, press and hold the programming button until the LED flashes once.

FEATURES:

- 1- Doorlock Output: LOCK=Unlock All Doors, UNLOCK=1st pulse unlocks driver door, 2nd pulse unlocks all doors
- 8- Module Reset: LOCK or UNLOCK will reset the module to factory default

POWER REAR HATCH CONTROL:

The power rear hatch can be operated by either applying a 3 second negative pulse to the ORANGE wire only or by applying a 0.75 negative pulse the ORANGE and PINK wires- diode isolation required; cathode (band) face away from interface module.