



IB-F3 Installation Instructions

FORD & MAZDA TRANSPONDER BYPASS KIT (NO KEY REQUIRED)





IB-F3 MODULE PROGRAMMING

Programming is similar to Ford additional key programming.

IMPORTANT: TWO VALID KEYS ARE NECESSARY TO PROGRAM MODULE. MAXIMUM 5 SECOND INTERVALS BETWEEN EACH STEP

- **1-** Insert the first valid key into ignition.
 - Turn key to ignition "ON" position and wait until the **IB-F3** LED turns off. Turn Ignition key to "OFF" position and remove.
- 2- Insert the 2nd valid key into ignition.
 - Turn key to ignition "ON" position and wait until the **IB-F3** LED turns off. Turn Ignition key to "OFF" position and remove
- **3-** Temperarily connect the brown wire of **IB-F3** module to ground. Then using a jumper wire apply power to the vehicle ignition wire. The LED on the PKF-3 module flash once then come on again for three seconds. The PKF-3 is now programmed.
- **4-** Connect the brown wire of the **IB-F3** module to the remote car starter (-) negative out when running wire. (ground out when running)

			Year					
	Make	Model	'05	'04	,03	'02	'01	'01
	Ford	Crown Victoria		~	~			
		Escape	~					
		Expedition		~	~	~		
		Explorer		~	~	~	1	
		F150		~				
		Freestar		~				
		Ranger		~	~	~	1	
		Taurus		~	~	~	~	~
		Thunderbird		~	~			
₽		Windstar		~	~	~	1	
PKF3	Lincoln	Aviator		~	~			
		Blackwood		~	~			
		Continental		~	~	~		
		LS		~				
		Navigator		~	~	~		
		Town Car		~	~			
	Mazda	B3000		~	~	~		
		B4000		~	~	~		
		Tribute	~					
	Mercury	Grand Marquis		~	~			
		Marauder		~	~			
		Mountaineer		~	~	~	1	
		Sable		~	~	~	~	~