



**[www.caralarm.com](http://www.caralarm.com)**


**BT-8L2**  
**BT-10L2**  
**BT-12L2**



# **Installation Instructions**


# Mounting The Enclosure

Method 1




| L+         | L-  | R+     | R-     |
|------------|-----|--------|--------|
| Switch 12v | 12v | Ground | Ground |

Method 2



# Wiring Diagram

Method 1 (Speaker Level Inputs)



Method 2 (Line Level Inputs)

