


DB-CHDL4 Installation Instructions

2003-04 JEEP LIBERTY DOORLOCK INTEGRATION MODULE

Provides Lock, Unlock, Rear Hatch, OEM Alarm Arm, OEM Alarm Disarm, Parking Lights, RAP Shutdown



FEATURES PROGRAMMING (ONLY FEATURE 1 IS AVAILABLE)

- 1-With the Key in the "OFF" position, press and hold program button for 2 seconds, the LED will flash for 3 seconds and then once more to indicate Feature 1.
- 2-To change the setting, press LOCK or UNLOCK on the after market transmitter.
- 3-Horn will chirp once or twice to indicate each setting.
- 4-To exit programming, press and hold button until the LED flashes once.

IMPORTANT: DO NOT CONNECT VIOLET DATA OUTPUT WIRE OF INTERFACE MODULE TO VEHICLE DATA WIRE (PIN 2) UNTIL EVERY OTHER WIRE HAS BEEN CONNECTED & THE HARNESS HAS BEEN PLUGGED INTO THE DATA BUS INTERFACE (DL) MODULE.

PROGRAMMABLE FEATURES LIST:

ONLY FEATURE 1 is AVAILABLE

(* = DEFAULT SETTING)

FEATURE 1 -UNLOCK :

- *PRESS LOCK= 1Driver's door priority unlocking
- PRESS UNLOCK = 1 pulse: unlock all doors

DATA BUS DOORLOCK PROGRAMMING

Once the module is properly installed, start the vehicle by key. The horn will sound 1 to 5 chirps. The Data Bus Doorlock Interface module is now programmed.