
DB-JDL3 Installation Instructions

JEEP GRAND CHEROKEE DOORLOCK INTERFACE MODULE

Lock/Unlock, Driver's Door Priority Unlock, OEM Alarm Arm/Disarm, Panic, Domelight trigger bypass



DATABUS DOORLOCK PROGRAMMING:

Turn key to the ignition ON position.

Horn will sound 1 to 5 chirps.

The Data Bus Doorlock Interface module is now programmed.

TECH NOTES:

- *NOTE 1 Vehicle will Disarm before Remote Starting and will Re-Arm after Remote Starter is shut down.
- **NOTE 2 The factory security will arm when this input sees ground as well as lock all doors & Roll Up Windows (Jumper B).
- ***NOTE 3 The factory security will disarm when this input sees ground as well as unlock the doors.
- ****NOTE 4 Memory Functions (seat, mirror & radio) will only work if Violet/White "Driver Door Input" wire is connected.

IMPORTANT:

Remote alarm combination systems only- (see Fig. C. above for relay configuration).

For reliable conversion of analog to digital, all (-) input wires require a solid ground to activate each command function.

Model \ Year	'04	'03	'02	'01	'00	'99
Grand Cherokee	~	✓	~	~	~	~
Grand Cherokee Limited	/	~	~	~	~	~