


IB-M1 Installation Instructions

MAZDA TRANSPONDER BYPASS KIT (NO KEY REQUIRED)

* See Select Vehicle List Below



PROGRAMMING IB-M1

When the IB-M1 is correctly installed, Put the programming jumper to the "Programming" position (The LED must be "On") turn the ignition key to the "ON" position and start the vehicle. When the **IB-M1** is programmed the LED will blink. Turn the Ignition to the "OFF" position and remove the programming jumper (the LED will stop blinking).

COMPATIBLE VEHICLES:

MIATA	2001-2003
MPV	2001-2004

Under no circumstances shall the manufacturer and/or distributors of the (IB-M1) parts are liable for consequential damages sustained in connection with the (IB-M1). Neither assumes nor authorizes any representative or other person to assume for it any obligation or liability other than the replacement of the (IB-M1) parts it self.


Omega Research & Development Inc. 2004

IS_IB-M1 10/25/04

IB-M1 Installation Instructions

MAZDA TRANSPONDER BYPASS KIT (NO KEY REQUIRED)

* See Select Vehicle List Below



PROGRAMMING IB-M1

When the IB-M1 is correctly installed, Put the programming jumper to the "Programming" position (The LED must be "On") turn the ignition key to the "ON" position and start the vehicle. When the **IB-M1** is programmed the LED will blink. Turn the Ignition to the "OFF" position and remove the programming jumper (the LED will stop blinking).

COMPATIBLE VEHICLES:

MIATA	2001-2003
MPV	2001-2004

Under no circumstances shall the manufacturer and/or distributors of the (IB-M1) parts are liable for consequential damages sustained in connection with the (IB-M1). Neither assumes nor authorizes any representative or other person to assume for it any obligation or liability other than the replacement of the (IB-M1) parts it self.

Omega Research & Development Inc. 2004

IS_IB-M1 10/25/04