Firmware: PKH4

Installation Manual (1\1 Pages)

Description: Honda/Acura Transponder Interface: TYPE "C" (7 Wire Connector)

Functions: Override OEM Transponder Immobilizer Via Data (NO KEY REQUIRED)

Downloadable Firmware for Platform #05: PKG3,PKG8,PKH1, PKH2,PKH3,PKH4,PKHY1,PKM2,PKN2,PKT2 WARNING: Before beginning your install go to www.INTELLIKITS.com and be sure to print the LATEST corresponding installation manual

for the firmware that is flashed to the platform you are using. See Wire Connection Guide for detailed information regarding wire functionality Section A Internet 2006 HONDA CIVIC and ACURA CSX Option A Firmware Upgrades **USB** Cable **USB** Adaptor **D2D** 4 PIN DATA TO DATA (D2D) CABLE (OPTIONAL ACCESSORY)

Ground When Running


N/C

N/C

UPGRADEABLE OVERRIDE OEM TRANSPONDER **IMMOBILIZER** VIA DATA

LED






N/C

Brown

Violet/White



Option B - Data 2 Data Connection to RCS Data Port

Section B

WIRE GUIDE: CONNECTIONS

INPUT

N/C

5

PZ

D2D = Optional use of 4 Pin Data to Data (D2D) cable will replace the analogue wire (w2w) connection

een N/C ue N/C blet/ N/C hite blet w2w	2w //C N/C //C N/C //C N/C	(-) N/C N/C N/C	N/C N/C N/C	Ground When Running Output of Remote Starter N/C N/C N/C Connect to Light Green Data Wire PIN 3 of the White 7	Immobilizer Bypass Via Data N/C N/C N/C Data Commands from Module to Vehicle
ue N/C olet/ N/C hite	/C N/C /C N/C	N/C N/C	N/C N/C Vehicle	N/C N/C	N/C N/C
olet/ N/C hite	/C N/C	N/C N/C	N/C Vehicle	N/C	N/C
hite		N/C	Vehicle		1
olet w2w	2w Data			Connect to Light Green Data Wire PIN 3 of the White 7	Data Commanda from Madula to Vahiala
				PIN connector located on key cylinder.	Data Commanus from Module to Venicle
nk/ N/C	/C N/C	N/C	N/C	N/C	N/C
ink N/C	/C N/C	N/C	N/C	N/C	N/C
ange N/C	/C N/C	N/C	N/C	N/C	N/C
		(+)	Vehicle	Constant (+) 12 Volt Source	Power Source
		(-)	Vehicle	Chassis Ground	Ground Source
e	nge N d Di wi	nge N/C N/C d D2D Input w2w	N/C N/C N/C D2D Input (+) ck D2D Input (-)	age N/C N/C N/C N/C d D2D Input (+) Vehicle ck D2D Input (-) Vehicle	lage N/C N/C N/C N/C dd D2D w2w Input w2w (+) Vehicle Constant (+) 12 Volt Source ck D2D Input (-) Vehicle Chassis Ground

N/C = No Connection

N/A = Not Applicable W2W= analogue wire to wire D2D= data 2 data

DATA to DATA PORT (D2D): Blue connector of D2D Cable plugs into the upgradeable vehicle interface module.

OPTION A: - D2D Port used to connect to USB Bootloader adaptor & computer to download & flash vehicle interface firmware. OPTION B: - D2D Port used to connect to the data port of a remote control system equipped with ClearCode Vehicle Interface Protocol.

Remote control systems designed with ClearCode VIP can securely communicate via the D2D cable to transmit & receive data commands which initiate specific vehicle function such as doorlocks & immobilizer override and /or request information from the vehicle such as status of entry points (doors) or ambiant température, diesel glow plug etc... ClearCode VIP represents the doorway to vehicle integration...As an enhanced security feature, this upgradeable vehicle interface module automatically detects when the Vehicle Interface Protocol is present and deactivates the analogue override input wire (brown wire) ensuring that this module can only be activated by an authorized user.

VEHICLE PROGRAMMING

- 1) Once module has been properly connected, turn key to IGNITION position, LED goes on.
- 2) After LED turns OFF, module is now programmed.

*To RESET, press and hold button and plug in module. LED comes on. When LED goes off, release button.

This Interface kit / Data Bus Interface part has been tested on the listed vehicles. Other vehicles will be added to the select vehicle list upon completion of compatibility testing. Visit website for latest vehicle application guide. DISCLAIMER: Under no circumstances shall the manufacturer or the distributors of the bypass kit / data bus interface part(s) be held liable for any consequential damages sustained in connection with the part(s) installation. The manufacturer and it's distributors will not, nor will they authorize any representative or any other individual to assume obligation or liablity in relation to the interface kit / data bus interface part(s) other than its replacement. N.B.: Under no circumstances shall the manufacturer and distributors of this product are liable for consequential damages sustained in connection with this product neither assumes nor authorizes any representative or other person to assume for it any obligation or liablity other than the replacement of this product only.